

Colour Porcelain Crockery

AV&T[®]
www.avnt.co.in

Nakato
— PORCELAIN —

AV&T[®] GAOAN[®]
RFID LOCK

 KingSafe

AV&T[®]

PEARL EDITION

DESERT EDITION

Vakato

PORCELAIN

GLASSY EDITION

FINE ART





PEARL



DESERT



GLASSY



FINE ART




PRODUCT GUIDANCE






Quality

Our Premium Fine Porcelain has the composition of Kaolin, Ball Clay, Feldspar and Silica, we have created our own glaze formula and use pure raw materials with the finest quality. Being fired at 1,250°C, this temperature range makes the products durable for serving all functional usage with 0% water absorption. Besides, our products are specially designed to maximize strength, reduce cracking and chipping.




Design & Function

Our products are designed with multi-functional concept aiming to be a smart solution for all different purposes. For example, various creative stackable items suit the idea of storage and facilitates space saving.



Dishwasher & Microwave Safe

The products are safe to use with industrial dishwashing machine. The glaze and decoration do not stain or loss their brilliance or color. With dishwashing machine, it can be in excess of 1,000 cycles. Our products are also guaranteed to be completely microwave safe.



Thermal Shock & Crazing Resistance

Our products are tested at the extreme temperature condition. The products can resist the sudden change from freezer to microwave.



Lead & Cadmium Free

Our Products are tested and passed the lead & cadmium free under standard test FDA, California Proposition 65 and EU Directive 84/500 EEC. Our product is safe and hygienic to be used as food container.



Cut & Scratch Resistance

The hardness of our glaze prevents any cut & scratch remaining on the surface. We pay special attention to polish and form the foot of our tableware in order to guarantee a smooth foot to reduce the risk of abrasion and scratching during stacking.

GEM SERIES

Color glaze and Matt Glaze finishes on product will tend to show ware and tear to a greater degree. Please use the product with special care to extend its life cycle and to preserve its appearance.

SATIN SERIES

Color glaze and Matt Glaze finishes on product will tend to show ware and tear to a greater degree. Please use the product with special care to extend its life cycle and to preserve its appearance.

SAND SERIES

Color glaze and Matt Glaze finishes on product will tend to show ware and tear to a greater degree. Please use the product with special care to extend its life cycle and to preserve its appearance.

PEARL EDITION

PEARL EDITION shine every second the memorable moment. This special luster styling will delight your dining experience.



- LIGHT GREY
- BEIGE
- BROWN
- GREY
- MINT
- NAVY BLUE



Pearl edition shines every second of the memorable moment. This special lustre styling will delight your dining experience.

Colours Available

- LIGHT GREY
- BEIGE
- BROWN
- GREY
- MINT
- NAVY BLUE

Light Grey



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



75524A
BOWL
18 cm. (7")



75517A
BOWL
13 cm. (5.12")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")



75529A
BOWL
16 cm. (6.3")

Light Grey



75600A

CUP
100 cc. (3.38 Oz.)

75301A

SAUCER
12.5 cm. (4.92")



75611A

CUP
200 cc. (6.76 Oz.)

75302A

SAUCER
15 cm. (5.9")



75616A

CUP
250 cc. (8.45 Oz.)

75302A

SAUCER
15 cm. (5.9")



75601A

CUP A
100 cc. (3.38 Oz.)

75307A

SAUCER
12.5 cm. (4.92")



75612A

CUP A
200 cc. (6.76 Oz.)

75308A

SAUCER
15 cm. (5.9")



75617A

CUP A
250 cc. (8.45 Oz.)

75308A

SAUCER
15 cm. (5.9")



75605A

CUP B
100 cc. (3.38 Oz.)

75301A

SAUCER
12.5 cm. (4.92")



75615A

CUP B
200 cc. (6.76 Oz.)

75302A

SAUCER
15 cm. (5.9")



75620A

CUP B
250 cc. (8.45 Oz.)

75302A

SAUCER
15 cm. (5.9")



75641A

CUP
350 cc. (11.8 Oz.)

75309A

SAUCER
16 cm. (6.3")



75642A

CUP A
350 cc. (11.8 Oz.)

75310A

SAUCER
16 cm. (6.3")



75643A

CUP B
350 cc. (11.8 Oz.)

75309A

SAUCER
16 cm. (6.3")



75621A

MUG
250 cc. (8.45 Oz.)



75626A

MUG
300 cc. (10.15 Oz.)



75631A

MUG
350 cc. (11.8 Oz.)



75625A

MUG B
250 cc. (8.45 Oz.)



75622A

MUG A
250 cc. (8.45 Oz.)



75627A

MUG A
300 cc. (10.15 Oz.)



75633A

MUG A
350 cc. (11.8 Oz.)



75634A

MUG B
350 cc. (11.8 Oz.)

Light Grey



Light Grey

SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



75044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")



75045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")



75205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



75202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")



75527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



75556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")

Beige



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



75524A
BOWL
18 cm. (7")



75517A
BOWL
13 cm. (5.12")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")



75529A
BOWL
16 cm. (6.3")

Beige



Beige



75600A

CUP
100 cc. (3.38 Oz.)

75301A

SAUCER
12.5 cm. (4.92")



75611A

CUP
200 cc. (6.76 Oz.)

75302A

SAUCER
15 cm. (5.9")



75616A

CUP
250 cc. (8.45 Oz.)

75302A

SAUCER
15 cm. (5.9")



75601A

CUP A
100 cc. (3.38 Oz.)

75307A

SAUCER
12.5 cm. (4.92")



75612A

CUP A
200 cc. (6.76 Oz.)

75308A

SAUCER
15 cm. (5.9")



75617A

CUP A
250 cc. (8.45 Oz.)

75308A

SAUCER
15 cm. (5.9")



75605A

CUP B
100 cc. (3.38 Oz.)

75301A

SAUCER
12.5 cm. (4.92")



75615A

CUP B
200 cc. (6.76 Oz.)

75302A

SAUCER
15 cm. (5.9")



75620A

CUP B
250 cc. (8.45 Oz.)

75302A

SAUCER
15 cm. (5.9")



75641A

CUP
350 cc. (11.8 Oz.)

75309A

SAUCER
16 cm. (6.3")



75642A

CUP A
350 cc. (11.8 Oz.)

75310A

SAUCER
16 cm. (6.3")



75643A

CUP B
350 cc. (11.8 Oz.)

75309A

SAUCER
16 cm. (6.3")



75621A

MUG
250 cc. (8.45 Oz.)



75626A

MUG
300 cc. (10.15 Oz.)



75631A

MUG
350 cc. (11.8 Oz.)



75625A

MUG B
250 cc. (8.45 Oz.)



75622A

MUG A
250 cc. (8.45 Oz.)



75627A

MUG A
300 cc. (10.15 Oz.)



75633A

MUG A
350 cc. (11.8 Oz.)



75634A

MUG B
350 cc. (11.8 Oz.)

Beige

SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.

**75044A**

FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")

**75045A**

FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")

**75205A**

DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")

**75202A**

DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")

**75527A**

BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")

**75556A**

BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")

Brown

**75600A**

CUP

100 cc. (3.38 Oz.)

75301A

SAUCER

12.5 cm. (4.92")

**75611A**

CUP

200 cc. (6.76 Oz.)

75302A

SAUCER

15 cm. (5.9")

**75616A**

CUP

250 cc. (8.45 Oz.)

75302A

SAUCER

15 cm. (5.9")

**75601A**

CUP A

100 cc. (3.38 Oz.)

75307A

SAUCER

12.5 cm. (4.92")

**75612A**

CUP A

200 cc. (6.76 Oz.)

75308A

SAUCER

15 cm. (5.9")

**75617A**

CUP A

250 cc. (8.45 Oz.)

75308A

SAUCER

15 cm. (5.9")

**75605A**

CUP B

100 cc. (3.38 Oz.)

75301A

SAUCER

12.5 cm. (4.92")

**75615A**

CUP B

200 cc. (6.76 Oz.)

75302A

SAUCER

15 cm. (5.9")

**75620A**

CUP B

250 cc. (8.45 Oz.)

75302A

SAUCER

15 cm. (5.9")

**75641A**

CUP

350 cc. (11.8 Oz.)

75309A

SAUCER

16 cm. (6.3")

**75642A**

CUP A

350 cc. (11.8 Oz.)

75310A

SAUCER

16 cm. (6.3")

**75643A**

CUP B

350 cc. (11.8 Oz.)

75309A

SAUCER

16 cm. (6.3")

**75621A**

MUG

250 cc. (8.45 Oz.)

**75626A**

MUG

300 cc. (10.15 Oz.)

**75631A**

MUG

350 cc. (11.8 Oz.)

**75625A**

MUG B

250 cc. (8.45 Oz.)

**75622A**

MUG A

250 cc. (8.45 Oz.)

**75627A**

MUG A

300 cc. (10.15 Oz.)

**75633A**

MUG A

350 cc. (11.8 Oz.)

**75634A**

MUG B

350 cc. (11.8 Oz.)

Brown



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



75524A
BOWL
18 cm. (7")



75517A
BOWL
13 cm. (5.12")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")



75529A
BOWL
16 cm. (6.3")

Brown



Brown

SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



75044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")



75045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")



75205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



75202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")



75527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



75556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")

Grey



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



75524A
BOWL
18 cm. (7")



75517A
BOWL
13 cm. (5.12")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")



75529A
BOWL
16 cm. (6.3")

Grey



Grey

**75600A**CUP
100 cc. (3.38 Oz.)**75301A**SAUCER
12.5 cm. (4.92")**75611A**CUP
200 cc. (6.76 Oz.)**75302A**SAUCER
15 cm. (5.9")**75616A**CUP
250 cc. (8.45 Oz.)**75302A**SAUCER
15 cm. (5.9")**75601A**CUP A
100 cc. (3.38 Oz.)**75307A**SAUCER
12.5 cm. (4.92")**75612A**CUP A
200 cc. (6.76 Oz.)**75308A**SAUCER
15 cm. (5.9")**75617A**CUP A
250 cc. (8.45 Oz.)**75308A**SAUCER
15 cm. (5.9")**75605A**CUP B
100 cc. (3.38 Oz.)**75301A**SAUCER
12.5 cm. (4.92")**75615A**CUP B
200 cc. (6.76 Oz.)**75302A**SAUCER
15 cm. (5.9")**75620A**CUP B
250 cc. (8.45 Oz.)**75302A**SAUCER
15 cm. (5.9")**75641A**CUP
350 cc. (11.8 Oz.)**75309A**SAUCER
16 cm. (6.3")**75642A**CUP A
350 cc. (11.8 Oz.)**75310A**SAUCER
16 cm. (6.3")**75643A**CUP B
350 cc. (11.8 Oz.)**75309A**SAUCER
16 cm. (6.3")**75621A**MUG
250 cc. (8.45 Oz.)**75626A**MUG
300 cc. (10.15 Oz.)**75631A**MUG
350 cc. (11.8 Oz.)**75625A**MUG B
250 cc. (8.45 Oz.)**75622A**MUG A
250 cc. (8.45 Oz.)**75627A**MUG A
300 cc. (10.15 Oz.)**75633A**MUG A
350 cc. (11.8 Oz.)**75634A**MUG B
350 cc. (11.8 Oz.)

Grey

SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



75044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")



75045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")



75205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



75202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")



75527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



75556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")

Mint



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")




75524A
BOWL
18 cm. (7")



75517A
BOWL
13 cm. (5.12")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")



75529A
BOWL
16 cm. (6.3")

Mint



75600A

CUP
100 cc. (3.38 Oz.)

75301A

SAUCER
12.5 cm. (4.92")



75611A

CUP
200 cc. (6.76 Oz.)

75302A

SAUCER
15 cm. (5.9")



75616A

CUP
250 cc. (8.45 Oz.)

75302A

SAUCER
15 cm. (5.9")



75601A

CUP A
100 cc. (3.38 Oz.)

75307A

SAUCER
12.5 cm. (4.92")



75612A

CUP A
200 cc. (6.76 Oz.)

75308A

SAUCER
15 cm. (5.9")



75617A

CUP A
250 cc. (8.45 Oz.)

75308A

SAUCER
15 cm. (5.9")



75605A

CUP B
100 cc. (3.38 Oz.)

75301A

SAUCER
12.5 cm. (4.92")



75615A

CUP B
200 cc. (6.76 Oz.)

75302A

SAUCER
15 cm. (5.9")



75620A

CUP B
250 cc. (8.45 Oz.)

75302A

SAUCER
15 cm. (5.9")



75641A

CUP
350 cc. (11.8 Oz.)

75309A

SAUCER
16 cm. (6.3")



75642A

CUP A
350 cc. (11.8 Oz.)

75310A

SAUCER
16 cm. (6.3")



75643A

CUP B
350 cc. (11.8 Oz.)

75309A

SAUCER
16 cm. (6.3")



75621A

MUG
250 cc. (8.45 Oz.)



75626A

MUG
300 cc. (10.15 Oz.)



75631A

MUG
350 cc. (11.8 Oz.)



75625A

MUG B
250 cc. (8.45 Oz.)



75622A

MUG A
250 cc. (8.45 Oz.)



75627A

MUG A
300 cc. (10.15 Oz.)



75633A

MUG A
350 cc. (11.8 Oz.)



75634A

MUG B
350 cc. (11.8 Oz.)

Mint



Mint

SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



75044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")



75045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")



75205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



75202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")



75527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



75556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")

Navy Blue



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75002A
COUPE PLATE
16 cm. (6.3")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75511A
BOWL
12 cm. (4.72")



75531A
LOW BOWL
17 cm. (6.7")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75022A
COUPE PLATE
21 cm. (8.27")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75521A
BOWL
15 cm. (5.9")



75532A
LOW BOWL
19 cm. (7.48")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75052A
COUPE PLATE
26 cm. (10.24")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75524A
BOWL
18 cm. (7")



75533A
LOW BOWL
21 cm. (8.27")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75072A
COUPE PLATE
30 cm. (11.8")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75517A
BOWL
13 cm. (5.12")



75529A
BOWL
16 cm. (6.3")

Navy Blue

**75600A**CUP
100 cc. (3.38 Oz.)**75301A**SAUCER
12.5 cm. (4.92")**75611A**CUP
200 cc. (6.76 Oz.)**75302A**SAUCER
15 cm. (5.9")**75616A**CUP
250 cc. (8.45 Oz.)**75302A**SAUCER
15 cm. (5.9")**75601A**CUP A
100 cc. (3.38 Oz.)**75307A**SAUCER
12.5 cm. (4.92")**75612A**CUP A
200 cc. (6.76 Oz.)**75308A**SAUCER
15 cm. (5.9")**75617A**CUP A
250 cc. (8.45 Oz.)**75308A**SAUCER
15 cm. (5.9")**75605A**CUP B
100 cc. (3.38 Oz.)**75301A**SAUCER
12.5 cm. (4.92")**75615A**CUP B
200 cc. (6.76 Oz.)**75302A**SAUCER
15 cm. (5.9")**75620A**CUP B
250 cc. (8.45 Oz.)**75302A**SAUCER
15 cm. (5.9")**75641A**CUP
350 cc. (11.8 Oz.)**75309A**SAUCER
16 cm. (6.3")**75642A**CUP A
350 cc. (11.8 Oz.)**75310A**SAUCER
16 cm. (6.3")**75643A**CUP B
350 cc. (11.8 Oz.)**75309A**SAUCER
16 cm. (6.3")**75621A**MUG
250 cc. (8.45 Oz.)**75626A**MUG
300 cc. (10.15 Oz.)**75631A**MUG
350 cc. (11.8 Oz.)**75625A**MUG B
250 cc. (8.45 Oz.)**75622A**MUG A
250 cc. (8.45 Oz.)**75627A**MUG A
300 cc. (10.15 Oz.)**75633A**MUG A
350 cc. (11.8 Oz.)**75634A**MUG B
350 cc. (11.8 Oz.)

Navy Blue



Navy Blue

SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.




75044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")



75045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")



75205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



75202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")



75527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



75556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")

DESERT EDITION

DESERT EDITION were blended the unique texture details together to create the story of timeless touch and reveal the joy of natural phenomena,satisfying all pleasure demands.



Black



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



75524A
BOWL
18 cm. (7")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")

Black

**75600A**CUP
100 cc. (3.38 Oz.)**75301A**SAUCER
12.5 cm. (4.92")**75611A**CUP
200 cc. (6.76 Oz.)**75302A**SAUCER
15 cm. (5.9")**75616A**CUP
250 cc. (8.45 Oz.)**75302A**SAUCER
15 cm. (5.9")**75601A**CUP A
100 cc. (3.38 Oz.)**75307A**SAUCER
12.5 cm. (4.92")**75612A**CUP A
200 cc. (6.76 Oz.)**75308A**SAUCER
15 cm. (5.9")**75617A**CUP A
250 cc. (8.45 Oz.)**75308A**SAUCER
15 cm. (5.9")**75641A**CUP
350 cc. (11.8 Oz.)**75309A**SAUCER
16 cm. (6.3")**75642A**CUP A
350 cc. (11.8 Oz.)**75310A**SAUCER
16 cm. (6.3")**75621A**MUG
250 cc. (8.45 Oz.)**75626A**MUG
300 cc. (10.15 Oz.)**75631A**MUG
350 cc. (11.8 Oz.)**75622A**MUG A
250 cc. (8.45 Oz.)**75627A**MUG A
300 cc. (10.15 Oz.)**75633A**MUG A
350 cc. (11.8 Oz.)

Black



Black

SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.

**75044A**

FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")

**75045A**

FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")

**75205A**

DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")

**75202A**

DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")

**75527A**

BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")

**75556A**

BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")

Black



75600A

CUP
100 cc. (3.38 Oz.)

75301A

SAUCER
12.5 cm. (4.92")



75611A

CUP
200 cc. (6.76 Oz.)

75302A

SAUCER
15 cm. (5.9")



75616A

CUP
250 cc. (8.45 Oz.)

75302A

SAUCER
15 cm. (5.9")



75601A

CUP A
100 cc. (3.38 Oz.)

75307A

SAUCER
12.5 cm. (4.92")



75612A

CUP A
200 cc. (6.76 Oz.)

75308A

SAUCER
15 cm. (5.9")



75617A

CUP A
250 cc. (8.45 Oz.)

75308A

SAUCER
15 cm. (5.9")



75641A

CUP
350 cc. (11.8 Oz.)

75309A

SAUCER
16 cm. (6.3")



75642A

CUP A
350 cc. (11.8 Oz.)

75310A

SAUCER
16 cm. (6.3")



75621A

MUG
250 cc. (8.45 Oz.)



75626A

MUG
300 cc. (10.15 Oz.)



75631A

MUG
350 cc. (11.8 Oz.)



75622A

MUG A
250 cc. (8.45 Oz.)



75627A

MUG A
300 cc. (10.15 Oz.)



75633A

MUG A
350 cc. (11.8 Oz.)

Beige



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



95201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



95524A
BOWL
18 cm. (7")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")

Beige



Blue



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")




75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



75524A
BOWL
18 cm. (7")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")

Blue

**75600A**CUP
100 cc. (3.38 Oz.)**75301A**SAUCER
12.5 cm. (4.92")**75611A**CUP
200 cc. (6.76 Oz.)**75302A**SAUCER
15 cm. (5.9")**75616A**CUP
250 cc. (8.45 Oz.)**75302A**SAUCER
15 cm. (5.9")**75601A**CUP A
100 cc. (3.38 Oz.)**75307A**SAUCER
12.5 cm. (4.92")**75612A**CUP A
200 cc. (6.76 Oz.)**75308A**SAUCER
15 cm. (5.9")**75617A**CUP A
250 cc. (8.45 Oz.)**75308A**SAUCER
15 cm. (5.9")**75641A**CUP
350 cc. (11.8 Oz.)**75309A**SAUCER
16 cm. (6.3")**75642A**CUP A
350 cc. (11.8 Oz.)**75310A**SAUCER
16 cm. (6.3")**75621A**MUG
250 cc. (8.45 Oz.)**75626A**MUG
300 cc. (10.15 Oz.)**75631A**MUG
350 cc. (11.8 Oz.)**75622A**MUG A
250 cc. (8.45 Oz.)**75627A**MUG A
300 cc. (10.15 Oz.)**75633A**MUG A
350 cc. (11.8 Oz.)

Beige

SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.

**75044A**

FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")

**75045A**

FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")

**75205A**

DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")

**75202A**

DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")

**75527A**

BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")

**75556A**

BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")

Blue



Blue

SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.

**75044A**

FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")

**75045A**


FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")

**75205A**


DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")

**75202A**

DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")

**75527A**

BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")

**75556A**

BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")

Grey



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")




75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



75524A
BOWL
18 cm. (7")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")

Grey



75600A

CUP
100 cc. (3.38 Oz.)

75301A

SAUCER
12.5 cm. (4.92")



75611A

CUP
200 cc. (6.76 Oz.)

75302A

SAUCER
15 cm. (5.9")



75616A

CUP
250 cc. (8.45 Oz.)



75601A

CUP A
100 cc. (3.38 Oz.)

75307A

SAUCER
12.5 cm. (4.92")



75612A

CUP A
200 cc. (6.76 Oz.)

75308A

SAUCER
15 cm. (5.9")



75617A

CUP A
250 cc. (8.45 Oz.)



75641A

CUP
350 cc. (11.8 Oz.)

75309A

SAUCER
16 cm. (6.3")



75642A

CUP A
350 cc. (11.8 Oz.)



75621A

MUG
250 cc. (8.45 Oz.)



75626A

MUG
300 cc. (10.15 Oz.)



75631A

MUG
350 cc. (11.8 Oz.)



75622A

MUG A
250 cc. (8.45 Oz.)



75627A

MUG A
300 cc. (10.15 Oz.)



75633A

MUG A
350 cc. (11.8 Oz.)

Grey



Grey

SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



75044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")



75045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")



75205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



75202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")



75527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



75556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")

Light Blue



Light Blue

SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



75044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")



75045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")



75205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



75202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")



75527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



75556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")

Light Blue



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")




75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



75524A
BOWL
18 cm. (7")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")

Light Blue



75600A

CUP
100 cc. (3.38 Oz.)

75301A

SAUCER
12.5 cm. (4.92")



75611A

CUP
200 cc. (6.76 Oz.)

75302A

SAUCER
15 cm. (5.9")



75616A

CUP
250 cc. (8.45 Oz.)

75302A

SAUCER
15 cm. (5.9")



75601A

CUP A
100 cc. (3.38 Oz.)

75307A

SAUCER
12.5 cm. (4.92")




75612A

CUP A
200 cc. (6.76 Oz.)

75308A

SAUCER
15 cm. (5.9")



75617A

CUP A
250 cc. (8.45 Oz.)

75308A

SAUCER
15 cm. (5.9")



75641A

CUP
350 cc. (11.8 Oz.)

75309A

SAUCER
16 cm. (6.3")



75642A

CUP A
350 cc. (11.8 Oz.)

75310A

SAUCER
16 cm. (6.3")



75621A

MUG
250 cc. (8.45 Oz.)



75626A

MUG
300 cc. (10.15 Oz.)



75631A

MUG
350 cc. (11.8 Oz.)



75622A

MUG A
250 cc. (8.45 Oz.)



75627A

MUG A
300 cc. (10.15 Oz.)



75633A

MUG A
350 cc. (11.8 Oz.)

Light Gray



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



75524A
BOWL
18 cm. (7")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")

Light Gray



75600A

CUP
100 cc. (3.38 Oz.)

75301A

SAUCER
12.5 cm. (4.92")



75611A

CUP
200 cc. (6.76 Oz.)

75302A

SAUCER
15 cm. (5.9")



75616A

CUP
250 cc. (8.45 Oz.)

75302A

SAUCER
15 cm. (5.9")



75601A

CUP A
100 cc. (3.38 Oz.)

75307A

SAUCER
12.5 cm. (4.92")



75612A

CUP A
200 cc. (6.76 Oz.)

75308A

SAUCER
15 cm. (5.9")



75617A

CUP A
250 cc. (8.45 Oz.)

75308A

SAUCER
15 cm. (5.9")



75641A

CUP
350 cc. (11.8 Oz.)

75309A

SAUCER
16 cm. (6.3")



75642A

CUP A
350 cc. (11.8 Oz.)

75310A

SAUCER
16 cm. (6.3")



75621A

MUG
250 cc. (8.45 Oz.)



75626A

MUG
300 cc. (10.15 Oz.)



75631A

MUG
350 cc. (11.8 Oz.)



75622A

MUG A
250 cc. (8.45 Oz.)



75627A

MUG A
300 cc. (10.15 Oz.)



75633A

MUG A
350 cc. (11.8 Oz.)

Light Gray



Light Gray

SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.

**75044A**

FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")

**75045A**

FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")

**75205A**

DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")

**75202A**

DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")

**75527A**

BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")

**75556A**

BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")

Red



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



75524A
BOWL
18 cm. (7")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")

Red



75600A

CUP
100 cc. (3.38 Oz.)

75301A

SAUCER
12.5 cm. (4.92")



75611A

CUP
200 cc. (6.76 Oz.)

75302A

SAUCER
15 cm. (5.9")



75616A

CUP
250 cc. (8.45 Oz.)

75302A

SAUCER
15 cm. (5.9")



75601A

CUP A
100 cc. (3.38 Oz.)

75307A

SAUCER
12.5 cm. (4.92")



75612A

CUP A
200 cc. (6.76 Oz.)

75308A

SAUCER
15 cm. (5.9")



75617A

CUP A
250 cc. (8.45 Oz.)

75308A

SAUCER
15 cm. (5.9")



75641A

CUP
350 cc. (11.8 Oz.)

75309A

SAUCER
16 cm. (6.3")



75642A

CUP A
350 cc. (11.8 Oz.)

75310A

SAUCER
16 cm. (6.3")



75621A

MUG
250 cc. (8.45 Oz.)



75626A

MUG
300 cc. (10.15 Oz.)



75631A

MUG
350 cc. (11.8 Oz.)



75622A

MUG A
250 cc. (8.45 Oz.)



75627A

MUG A
300 cc. (10.15 Oz.)



75633A

MUG A
350 cc. (11.8 Oz.)

Red



Red

SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



75044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")



75045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")



75205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



75202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")



75527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



75556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")

GLASSY EDITION

GLASSY EDITION were originated from irresistible desire to create distinguished style. It surely provides an inspiration to all types of cuisine.

- BLACK
- GREEN
- TAUPE



BLACK



95600A

CUP
100 cc. (3.38 Oz.)

95301A

SAUCER
12.5 cm. (4.92")



95611A

CUP
200 cc. (6.76 Oz.)

95302A

SAUCER
15 cm. (5.9")



95616A

CUP
250 cc. (8.45 Oz.)

95302A

SAUCER
15 cm. (5.9")



95601A

CUP A
100 cc. (3.38 Oz.)

95307A

SAUCER
12.5 cm. (4.92")



95612A

CUP A
200 cc. (6.76 Oz.)

95308A

SAUCER
15 cm. (5.9")



95617A

CUP A
250 cc. (8.45 Oz.)

95308A

SAUCER
15 cm. (5.9")



95641A

CUP
350 cc. (11.8 Oz.)

95309A

SAUCER
16 cm. (6.3")



95642A

CUP A
350 cc. (11.8 Oz.)

95310A

SAUCER
16 cm. (6.3")



95621A

MUG
250 cc. (8.45 Oz.)



95626A

MUG
300 cc. (10.15 Oz.)



95631A

MUG
350 cc. (11.8 Oz.)



95622A

MUG A
250 cc. (8.45 Oz.)



95627A

MUG A
300 cc. (10.15 Oz.)



95633A

MUG A
350 cc. (11.8 Oz.)

BLACK



95001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



95021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



95051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



95071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



95002A
COUPE PLATE
16 cm. (6.3")



95022A
COUPE PLATE
21 cm. (8.27")



95052A
COUPE PLATE
26 cm. (10.24")



95072A
COUPE PLATE
30 cm. (11.8")



95034A
DEEP COUPE PLATE
21.5 cm. (8.46")



95171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



95191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



95201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



95057A
DEEP COUPE PLATE
25.5 cm. (10")



95511A
BOWL
12 cm. (4.72")



95521A
BOWL
15 cm. (5.9")



95524A
BOWL
18 cm. (7")



95531A
LOW BOWL
17 cm. (6.7")



95532A
LOW BOWL
19 cm. (7.48")



95533A
LOW BOWL
21 cm. (8.27")

BLACK



BLACK

SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



95044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")



95045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")



95205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



95202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")



95527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



95556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")

Green



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



95072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



75524A
BOWL
18 cm. (7")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")

Green

**75600A**CUP
100 cc. (3.38 Oz.)**75301A**SAUCER
12.5 cm. (4.92")**75611A**CUP
200 cc. (6.76 Oz.)**75302A**SAUCER
15 cm. (5.9")**75616A**CUP
250 cc. (8.45 Oz.)**75302A**SAUCER
15 cm. (5.9")**75601A**CUP A
100 cc. (3.38 Oz.)**75307A**SAUCER
12.5 cm. (4.92")**75612A**CUP A
200 cc. (6.76 Oz.)**75308A**SAUCER
15 cm. (5.9")**75617A**CUP A
250 cc. (8.45 Oz.)**75308A**SAUCER
15 cm. (5.9")**75641A**CUP
350 cc. (11.8 Oz.)**75309A**SAUCER
16 cm. (6.3")**75642A**CUP A
350 cc. (11.8 Oz.)**75310A**SAUCER
16 cm. (6.3")**75621A**MUG
250 cc. (8.45 Oz.)**75626A**MUG
300 cc. (10.15 Oz.)**75631A**MUG
350 cc. (11.8 Oz.)**75622A**MUG A
250 cc. (8.45 Oz.)**75627A**MUG A
300 cc. (10.15 Oz.)**75633A**MUG A
350 cc. (11.8 Oz.)

Green



Taupe



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



95511A
BOWL
12 cm. (4.72")



95521A
BOWL
15 cm. (5.9")



95524A
BOWL
18 cm. (7")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")

Green

SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



75044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")



75045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")



75205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



75202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")



75527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



75556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")

Taupe



75600A
CUP
100 cc. (3.38 Oz.)

75301A
SAUCER
12.5 cm. (4.92")



75611A
CUP
200 cc. (6.76 Oz.)

75302A
SAUCER
15 cm. (5.9")



75616A
CUP
250 cc. (8.45 Oz.)

75302A
SAUCER
15 cm. (5.9")



75601A
CUP A
100 cc. (3.38 Oz.)

75307A
SAUCER
12.5 cm. (4.92")



75612A
CUP A
200 cc. (6.76 Oz.)

75308A
SAUCER
15 cm. (5.9")



75617A
CUP A
250 cc. (8.45 Oz.)

75308A
SAUCER
15 cm. (5.9")



75641A
CUP
350 cc. (11.8 Oz.)

75309A
SAUCER
16 cm. (6.3")



75642A
CUP A
350 cc. (11.8 Oz.)

75310A
SAUCER
16 cm. (6.3")



75621A
MUG
250 cc. (8.45 Oz.)



75626A
MUG
300 cc. (10.15 Oz.)



75631A
MUG
350 cc. (11.8 Oz.)



75622A
MUG A
250 cc. (8.45 Oz.)



75627A
MUG A
300 cc. (10.15 Oz.)



75633A
MUG A
350 cc. (11.8 Oz.)

Taupe

SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



75044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")



75045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")



75205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



75202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")



75527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



75556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")

Taupe



FINE ART

FINE ART is the real player on tabletop stage. Each motivation item performs its part supremely that magor magnificence atmosphere conveys, capturing the hearts of all audiences.



White



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75231A
OVAL PLATE
24 cm. (9.45")



75251A
OVAL PLATE
30 cm. (11.8")



75261A
OVAL PLATE
36 cm. (14")

White



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



75524A
BOWL
18 cm. (7")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")



75517A
BOWL
13 cm. (5.12")



75529A
BOWL
16 cm. (6.3")



75600A
CUP
100 cc. (3.38 Oz.)



75301A
SAUCER
12.5 cm. (4.92")



75601A
CUP A
100 cc. (3.38 Oz.)



75307A
SAUCER
12.5 cm. (4.92")



75605A
CUP B
100 cc. (3.38 Oz.)

75301A
SAUCER
12.5 cm. (4.92")



75621A
MUG
250 cc. (8.45 Oz.)



75806A
TEA POT WITH LID
500 cc. (17 Oz.)



75807A
TEA POT A WITH LID
500 cc. (17 Oz.)



75611A
CUP
200 cc. (6.76 Oz.)



75302A
SAUCER
15 cm. (5.9")

75616A
CUP
250 cc. (8.45 Oz.)

75302A
SAUCER
15 cm. (5.9")



75641A
CUP
350 cc. (11.8 Oz.)

75309A
SAUCER
16 cm. (6.3")



75612A
CUP A
200 cc. (6.76 Oz.)



75308A
SAUCER
15 cm. (5.9")

75617A
CUP A
250 cc. (8.45 Oz.)

75308A
SAUCER
15 cm. (5.9")



75642A
CUP A
350 cc. (11.8 Oz.)

75310A
SAUCER
16 cm. (6.3")



75615A
CUP B
200 cc. (6.76 Oz.)



75302A
SAUCER
15 cm. (5.9")

75620A
CUP B
250 cc. (8.45 Oz.)

75302A
SAUCER
15 cm. (5.9")



75643A
CUP B
350 cc. (11.8 Oz.)

75309A
SAUCER
16 cm. (6.3")



75626A
MUG
300 cc. (10.15 Oz.)



75631A
MUG
350 cc. (11.8 Oz.)



75622A
MUG A
250 cc. (8.45 Oz.)



75627A
MUG A
300 cc. (10.15 Oz.)



75633A
MUG A
350 cc. (11.8 Oz.)



75810A
TEA POT WITH LID
1,000 cc. (33.82 Oz.)



75811A
SUGAR BOWL
250 cc. (8.45 Oz.)



75817A
CREAMER
200 cc. (6.76 Oz.)



75625A
MUG B
250 cc. (8.45 Oz.)



75634A
MUG B
350 cc. (11.8 Oz.)



75809A
TEA POT A WITH LID
1,000 cc. (33.82 Oz.)



75812A
SUGAR BOWL A
200 cc. (6.76 Oz.)



75820A
CREAMER A
200 cc. (6.76 Oz.)



75903A
SHAKER 3 HOLES



75904A
SHAKER 1 HOLE



84



SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



75044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")




75045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")




75075A
FLAT PLATE / WIDE RIM A
30 cm. (11.8")
RIM 6.8 cm. (2.68")



75076A
FLAT PLATE / WIDE RIM A
30 cm. (11.8")
RIM 9 cm. (3.54")



75181A
DEEP PLATE / WIDE RIM
25 cm. (9.8")
WELL 12.2 cm. (4.8")



75203A
DEEP PLATE / WIDE RIM A
31 cm. (12")
WELL 15 cm. (5.9")



75204A
SQUARE GOURMET PLATE
30 cm. (11.8")
WELL 16.2 cm. (6.38")



75915A
COVER
15.5 cm. (6.1")
(Fits 95045A, 95203A)



75914A
COVER
19 cm. (7.48")
(Fits 95202A)



75205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



75202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")



75527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



75556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")



SHOWROOM

A18, Shanti Shopping Centre,
Near Railway Station
Mira Road Thane - 401107
Mumbai.

OFFICE

D-328, Shanti Shopping Centre,
Near Railway Station
Mira Road Thane - 401107
Mumbai.

Ph. 022-28115983,



9820461403 / 9930289998 / 9820435983



info@avnt.co.in



www.avnt.co.in

Our Clients

CONRAD
HOTELS & RESORTS

Marriott
HOTELS & RESORTS

Radisson
HOTELS & RESORTS

Hilton
HOTELS & RESORTS

SAROVAR
HOTELS & RESORTS

Holiday Inn

THE PARK
HOTELS

Le MERIDIEN
HOTELS & RESORTS

THE DEN
BANGALORE

Citrus
HOTELS

Lords
HOTELS & RESORTS

ibis
HOTELS

Kyriad
HOTEL

RAMADA

FOUR POINTS
BY SHERATON

ROYAL ORCHID
HOTEL

WYNDHAM
HOTEL GROUP

COURTYARD
Marriott

lemon tree
HOTELS

RENAISSANCE
HOTELS

NOVOTEL
HOTELS & RESORTS

GINGER
HOTELS

GOLDEN TULIP
HOTELS & RESORTS

CROWNE PLAZA
HOTELS & RESORTS

Cygnett
HOTELS & RESORTS

Fairmont
HOTELS & RESORTS

HYATT
PLACE

FOUR SEASONS

aloft
HOTELS

ST REGIS

